Pontoon Console Cover Installation Instructions:

Supplies you will need:

- Drill
- 9/64" drill bit
- Phillips head screwdriver
- Pencil
- Optional: silicone

Package includes:

- 1 console cover
- 8 screw studs



Cover is for storage only.

Steps to install the console cover:

- 1. Locate the I.D. tag on the inside of the cover. Center the cover on the console with the short sides to the front and starboard or right side (where the I.D. tag is located).
- 2. Using a pencil, carefully mark the location for each screw stud on the console as it corresponds with each snap on the cover.
- 3. Using the drill with the 9/64" drill bit, drill the pilot holes for the screw studs. When drilling into fiberglass, hollow out the pilot hole to avoid cracking fiberglass when installing the screw stud. If desired, a drop of silicone may be used to seal the screw hole.
- 4. Install the screw studs with the Phillips head screwdriver.
- 5. Install the cover beginning at the top, starboard side by attaching each snap to its corresponding screw stud.



Snaps installed on the console cover



Made in the USA!

Carver by Covercraft Industries, LLC

www.carvercovers.com 864.457.5820