



Installing a Carver CPR/CSR Boat Cover

Please take extra care when trying your boat cover on for the first time! Should you need to return the boat cover, it **MUST** be in its original, new condition. The cover must be clean and free of debris (including pet hair). Soiled, wet, mildewed, torn or otherwise mishandled covers cannot be accepted for exchange or credit.

When trailering, always use heavy-duty tie-downs, sold separately. Part #61000.

All Carver Boat Covers are rolled and packaged with the bow end of the cover to the outside. The tag on the bow end is sewn into the inside of the hem of the cover. To cover your boat, proceed as follows:

1. Place the bow end of the rolled cover on or near the bow of your boat and unroll towards the stern or back, positioning it down the center of the boat as you unroll.
2. Slip the front of the cover over the bow and pull the cover open to the sides as you work towards the back of the boat.
3. If using support poles (optional for most covers), position the poles under your cover prior to completely covering the boat.
4. Adjust cover fit by pulling cover tight to eliminate sagging areas. These areas may collect standing water or snow and shorten the life of your cover.
5. If the cover is designed to accommodate a boat with a Ski Tower, we have installed heavy-duty double pull buckles in the hem at the tower opening. These buckles provide a quick and easy initial adjustment at the openings and are also encased in the hem with a hook & loop closure shown in Figure A.
6. Tighten the cover using the pre-installed ratchet located at the back of the cover (Figure B). The ratchet is encased in a protective vinyl pouch secured in the hem with hook and loop fastener tape (Figures C & D). If excess webbing is present after tightening the cover, this is normal and the excess webbing may be trimmed. To keep the raw edge of the webbing from unraveling, singe it lightly with a cigarette lighter to fuse the yarns. Do not set the webbing on fire.
7. Using the reinforced tie-down loops, secure cover to your trailer with heavy-duty tie-downs. Two tie-down straps are pre-installed at the rear of the cover (Figure E). These must be secured to the trailer before trailering.
8. Remove the boat cover by folding both sides to the center and rolling the cover from back to front. This will make it easier to repeat Steps 1-7 when covering your boat again. Important: Allow the cover to dry thoroughly before folding for storage.

Ski boat CPR and CSR covers fit underneath the rub rail and grab rail (where applicable). To cover the swim platform, please see the boat cover accessories page at www.carvercovers.com for our separate swim platform covers or refer back to the guide for additional custom cover options that do provide bolt-on swim platform coverage.

For warranty information, please visit www.carvercovers.com/about-carver/product-warranty-information/.



Carver by Covercraft Industries, LLC

212 N. Lyles Ave., Landrum, SC 29356

More Information at CarverCovers.com
or call (888) 48-COVER.

The Best Covers Under the Sun™