


Westland

Extend The Shade Boat Shade Kit

Please Note
Max speed 45 mph

1. Locate the rod holders closest to the rear of your boat
2. Insert the bottom (white end) of one telescoping pole into the rod holders on the rear of the boat.
3. Adjust the telescoping poles to the desired height by pressing the button and extending them.
4. Connect the (3) long straps with quick release buckles to the sides and center of your T-Top frame
5. On the rear of the Extend the Shade there will be a rope attached thru a metal grommet and a rope ratchet at the opposite end. Attach this ratchet to the bracket on the extension pole. Leave the rope at full length for now.
6. Adjust all the straps for as much coverage as possible over the rear of the boat. The longer straps can now be trimmed and the ends melted with a lighter to prevent fraying of the strap. The rope needs to be left long to allow for easier install and removal later.



Westland Industries is not responsible for any injuries to persons or damages to the boat during assembly and installation of this product. Installation of this product may void your boat warranty, check with your dealer. Replace any worn parts to increase the life of your product. Do not use this product while the boat is underway.





WESTLAND LIMITED CONSUMER WARRANTY

All warranty inquiries must first be addressed with the retailer or dealer from which the Westland product was originally purchased. Do not return product directly to Westland without an RA number. No returns will be accepted without a RA number.

Westland Industries warrants, to the original purchaser, that its products are free from defects in material and workmanship for the periods listed below:

Hardware (3 Year Warranty) - Manufacturer Defects

WeatherMax 3D Fabric (5 Year Limited Warranty)

Warranty Conditions

Retailer Receipt or Proof of Purchase must be presented for any warranty transaction. Please keep your receipt and any tags removed from your products. Warranty takes effect from date of initial retail purchase. The original purchase date must be clearly displayed on the purchase receipt.

Warranty Items Not Covered

Not covered under warranty is damage caused by misuse, accident, neglect, improper installation, damage by exceeding the 45 Mph speed rating on the water or, trailering at any time behind your vehicle. Warranty is voided if your product is contaminated with tree sap, improper chemicals, bleach, gasoline, oils and other liquids not defined to be part of the normal cleaning procedure.

To read about proper cleaning and care procedures visit :

<https://westlandcovers.com/extend-the-shade-t-top-shade-extension.html> or, scan the QR Code at the bottom.

Additional items not covered include damage as a result of animals such as rodents, birds, pets, insects, etc. Product is also not covered if any damage is incurred as a result of coming into contact with sharp objects that would result in punctures or tears. Acid rain and exposure to other pollutants may also void warranty.

All incidental and/or consequential damages are excluded from the warranty. Implied warranties are limited to the life of the warranty. Some states do not allow limitations on how long an implied warranty lasts or the exclusion of incidental or consequential damages, so the above limitations may apply. This warranty gives you specific legal rights. You may also have other legal rights which typically vary from state to state.

Effective 7/11/19

Westland

